

Bemessungstabelle Konstruktionsvollholz (KVH)



Welchen KVH-Querschnitt benötige ich bei welchen Sparrenabstand ?

KN/m	Stützweite in m								
	1,0	1,5	2,0	2,5	3,0	3,5	4,0	4,5	5,0
0,5	6/8	6/10	6/10	6/10	6/12	6/14 – 8/12	6/16 – 8/14	8/16	8/18 – 10/16
0,7	6/8	6/10	6/10	6/12	6/14	6/14 – 8/12	8/14	8/18	8/20 – 10/18
0,9	6/8	6/10	6/10	6/12	6/14 – 8/12	6/14 – 8/12	6/16	8/20 – 10/18	8/22 – 10/20
1,1	6/8	6/10	6/10	6/12	6/14 – 8/12	6/16 – 8/14	8/18 – 10/16	10/18	8/22 – 10/20
1,3	6/8	6/10	6/10	6/14 – 8/12	6/16 – 8/14	6/18 – 8/16	8/18 – 10/16	10/20	8/24 – 10/20
1,5	6/8	6/10	6/10	6/14 – 8/12	6/16 – 8/14	6/18 – 8/16	8/20 – 10/18	12/20	10/24 – 12/20
1,7	6/8	6/10	6/12	6/14 – 8/12	6/16 – 8/14	6/20 – 8/18	8/20 – 10/18	12/22	10/24 – 12/22
1,9	6/8	6/10	6/12	6/14 – 8/12	6/18 – 8/16	6/20 – 8/18	8/22 – 10/20	10/24 – 12/22	10/24 – 12/22
2,1	6/10	6/10	6/12	6/16 – 8/14	6/18 – 8/16	6/20 – 8/18	8/24 – 10/20	10/24 – 12/22	10/24 – 12/22
2,3	6/10	6/10	6/12	6/16 – 8/14	6/18 – 8/16	6/24 – 8/20	8/24 – 10/20	12/24	12/24
2,5	6/10	6/10	6/12	6/16 – 8/14	6/20 – 8/18	6/24 – 8/20	10/20	12/24	12/24

Die Tabelle ist eine Vorbemessung und ersetzt nicht den statischen Nachweis